

# PRO GRIP WATER REPELLENT GROUT

**TECHNICAL DATA SHEET** 

#### **PURPOSE**

PRO GRIP WATER REPELLENT GROUT Is a specially formulated grouting compound with exceptional water repellent properties, making it ideal for use in permanently wet as well as underwater conditions, i.e. swimming pools and showers. This product includes MILDEW BLOCK which actively protects against the growth of algae and mildew.

## MIXING INSTRUCTIONS









- 1. Empty contents into a suitable container and slowly add cold water in the following ratios:
  - i. 1.75 Lt of water per 5 Kg bag of grout
  - ii. 7 Lt of water per 20 Kg bag of grout
- 2. For high stress application areas where additional mechanical or water resistance is required, replace the mixing water with PROGRIP BONDING LIQUID in the same mixing ratios.
- 3. Mix to a creamy consistency. The use of an electric drill and paddle is recommended to ensure thorough mixing.

# **SURFACE PREPARATION**

(These recommendations are in accordance with the SABS standard SANS 10107:2011 - The design and installation of ceramic tiles.)

- 1. The tile adhesive should be completely set before grouting can take place.
- 2. Ensure that joints to be grouted are sound (no cracks or crumbling), clean, free of dust and contaminants.
- 3. Ensure that the joints are free of excess tile adhesive.
- 4. Grout joints should be slightly moistened but not wet.

<sup>\*</sup>This guideline only serves as a basic manual for the surface preparation, product selection and installation procedure for this type of application. Each installation needs to be assessed on merits and the products used and the procedures followed should be in accordance with the SABS code for the design and installation of ceramic tiles (SABS 10107:2011).

### **APPLICATION**

- 1. Apply PROGRIP WATER REPELLENT TILE GROUT liberally to the surface and work into the joints with a grout squeegee taking care to completely fill the joint.
- 2. Remove excess grout and level the surface by moving the grout squeegee diagonally across the joints while the mix is still fresh.
- 3. Allow the grout to harden for 1 2 hours before removing the excess grout residue from the tiles with a damp (but not wet) sponge. Rinse the sponge frequently to achieve the best results.
- 4. Once the grout has completely set (after 24 Hrs), polish the tiles with a dry soft cloth. A wet cloth will not remove the thin film of grout residue.

#### **COVERAGE**

Since the coverage of this product is dependent upon the dimensions of the joints, the amount of grout required can be accurately determined by the following formula:-

Kg of grout per Square meter =  $\frac{(A + B) \times C \times D \times 1.7}{(A \times B)}$ 

Where

A = length of the tile in mm

B = width of the tile in mm

C = thickness of the tile in mm

D = average width of the joint in mm

As a guide, on average a 5 Kg bag of grout will grout an area of 8 - 10 m<sup>2</sup>

# **PRECAUTIONS**

- 1. Ensure that the above instructions are adhered to at all times and do not adulterate the product in any way as this could result in failure.
- 2. Rubber gloves should be used when applying PROGRIP WATER REPELLENT TILE GROUT <sup>®</sup>. In the event of irritation, rinse skin under cold water. Consult a doctor if irritation persists.
- 3. Keep PROGRIP WATER REPELLENT TILE GROUT ® away from pets and children.
- 4. Do not ingest and do not empty surplus adhesive down drains.

<sup>\*</sup>This guideline only serves as a basic manual for the surface preparation, product selection and installation procedure for this type of application. Each installation needs to be assessed on merits and the products used and the procedures followed should be in accordance with the SABS code for the design and installation of ceramic tiles (SABS 10107:2011).